



Fresnel Lens Replacement Instructions

1. Remove Smart Light from side of RV
2. While looking at the back of the fixture, use a small screwdriver to remove the two screws holding the left sensor.
3. Remove the old sensor lens.
4. Put new lens in place, smooth side out.
5. Using the two small screws, mount the sensor back into place.
6. Use the small screwdriver to remove the two screws holding the right sensor.
7. Remove old sensor lens.
8. Put new lens in place, smooth side out.
9. Using the two small screws, mount the sensor back into place.
10. Mount the Smart Light back on the side of the RV following the Installation and Operations Instructions.